



CPU FSB Select - JP2 and JP3

	JP2	JP3
Auto*	1-2 On	1-2 On
66MHz	2-3 On	2-3 On
100MHz	All Off	2-3 On
133MHz	All Off	All Off

*Auto denotes default

Clear CMOS Data - JP6

- 1-2 On: Normal (default)
- 2-3 On: Clear CMOS Data

Before clearing the CMOS data, make sure to power-off your system and unplug the power cord.

Onboard Audio Codec Settings - JP7 to JP9

- 1-2 On: Enable onboard audio codec (default)
- 2-3 On: Disable onboard audio codec

If you are using the (1) Wake-On-LAN/ or (2) Wake-On-Ring (internal modem) functions, the 5VSB power source of your power supply must support $\geq 720mA$.

If you are using the Suspend to RAM function, the 5VSB power source of your power supply must support $\geq 1A$.

The DIMM Standby Power LED will turn red when the system's power is on or when it is in the Suspend state (Power On Suspend or Suspend to RAM). It will not light when the system is in the Soft-Off state. The PCI Standby Power LED will turn red when the system is in the power-on, Soft-Off or Suspend (Power On Suspend or Suspend to RAM) state. Lighted LEDs serve as a reminder that you must power-off the system then turn off the power supply's switch or unplug the power cord prior to installing any DIM modules or add-in cards.

The AGP 4x LED will light when the AGP Pro Slot is installed with a 4x AGP card.

The frequency ratio of some processors shown in the table may have been locked by the manufacturer. If you are using this kind of processor, setting an extended ratio for the processor will have no effect. The system will instead use its factory default ratio.

Frequency Ratio Settings for Processors

Processor				Freq. Ratio	SW1	Processor				Freq. Ratio	SW1
66MHz	100MHz	133MHz				66MHz	100MHz	133MHz			
---	---	533MHz	4x	↑	8 1 2 3 4	433MHz	650MHz	866MHz	6.5x	↑	8 1 2 3 4
300MHz	---	600MHz	4.5x	↑	8 1 2 3 4	466MHz	700MHz	933MHz	7x	↑	8 1 2 3 4
333MHz	500MHz	667MHz	5x	↑	8 1 2 3 4	500MHz	750MHz	1GHz	7.5x	↑	8 1 2 3 4
366MHz	550MHz	733MHz	5.5x	↑	8 1 2 3 4	533MHz	800MHz	1.067GHz	8x	↑	8 1 2 3 4
400MHz	600MHz	800MHz	6x	↑	8 1 2 3 4						

The frequency ratio of processors greater than 8x has been locked by the manufacturer and will no longer have the flexibility of using extended ratios. Therefore, the system will use the processor's factory default ratio.

The voltage regulator will automatically be set according to the voltage of the processor.

At the time this document was printed, the CPU marked with asterisk (*) is not yet available. It is included in the table for reference only.